

Netgear Orbi
RBE873 MESH
SYSTEM SETUP


- Netgear Orbi RBE871 Router
- Netgear Orbi RBE870 Satellite
- Place your Orbi RBE871 router near modem. Use Ethernet cable and connect them both. Cable should connect into router's WAN and modem's LAN port.
- Power the modem and router on. Now, it's time to sync the satellite.
 Place the RBE870 on desired location and turn it.
- Press the Sync button at the back of the router and satellite. They both will connect with each other automatically.



- The next step is configuration. you can use either phone or computer for configuration. Let's start with the Orbi app. First download the Orbi app in your phone.
- Open the app, create the Netgear account, connect with the Orbi network, & enter the SSID username and password. Finish the setup.
- ➤ The second method is through the computer. For that, you need to connect your computer with the router network via WiFi or LAN cable.
- ▶ After connecting the devices, go into a web browser, search orbilogin.net or IP 192.168.1.1, and a login page will appear.

	TO REAL PROPERTY.
Login to Your Orbi	
To manage your Orbi, you'll need to login using your Orbi admin credentials.	
Username	
Password	
SIGN IN	
SIGN IN	

- Enter the admin details like username and password. The username is: admin & password is: password (default).
- You will access the interface, where in you have to enter the Orbi new SSID username and password. Then finish the setup by following a few prompts.
- After that, the Orbi mesh system will restarts itself and then you can connect with the mesh network wirelessly.





Thank You



Need Any Help?
Scan the QR code or
Visit: www.orbiloginet.com



